

شارژ کردن بسته باتری در سایر کشورها

شکل خروجی برق در کشورها و مناطق مختلف فرق می کند.
برای شارژ بسته باتری، به یک مبدل پریز برای تطابق با شکل خروجی نیاز دارید.

A	B	BF	C	O

North America	Europe	Oceania	Tyukintou
United States A	Iceland C	Australia O	Israel C
Canada A	Ireland C	Guam A	Iran C
Mexico A	United Kingdom B,BF	Tahiti C	Kuwait B,C
Asia	Italy C	Tonga O	Jordan B,BF
India B,C,BF	Austria C	New Zealand O	Africa
Indonesia C	Netherlands C	Fiji O	Algeria A,B,BF,C
Singapore B,BF	Canary Islands C	Latin	Egypt B,BF,C
Sri Lanka B,C,BF	Greece C	Argentina B,F,C,O	Guinea C
Thailand A,BF,C	Switzerland C	Colombia A	Kenya B,C
South Korea A,C	Sweden C	Jamaica A	Zambia B,BF
China A,B,BF,C,O	Spain A,C	Chile B,C	Tanzania B,BF
Nepal C	Denmark C	Haiti A	Republic of South Africa B,C,BF
Pakistan B,C	Germany C	Paraguay A	Mozambique C
Bangladesh C	Norway C	Bahamas A	Morocco C
Philippines A,BF,O	Hungary C	Puerto Rico A	
Vietnam A,C	Finland C	Brazil A,C	
Hong Kong Special B,BF	France C	Venezuela A	
Administrative Region	Belgium C	Peru A,C	
Macau Special B,C	Poland B,C		
Administrative Region	Portugal B,C		
Malaysia B,BF,C	Romania C		