



## Adding Title Screens to Playlists (GZ-HM350/GZ-HM330)

Add a title screen to a created playlist.

- 1 Select the playback mode.




- 2 Select video mode.



- 3 Touch to display the menu.



- 4 Select "EDIT PLAYLIST" and touch .



- 5 Select "SET TITLE" and touch .



- 6 Select the desired playlist and touch .



- Touch "CHECK" to check the content of the selected playlist.

- 7 Select a title and touch .



- Touch "CHECK" to check the title.

- To delete the title, select "NO TITLE".
- After setting, touch .
- To exit the screen, touch .