

Recording Menu (Video)

You can adjust various settings, such as brightness and white balance, to suit the subject or purpose. You can also change settings such as picture quality and gain.

| Setting | Details |
|----------------------|---|
| MANUAL SETTING | Recording settings can be adjusted manually. <ul style="list-style-type: none"> They are displayed only when recording in the manual mode. |
| FACE PRIORITY AE/AF | Detects faces and adjusts the brightness and focus automatically. |
| LIGHT | Turns on/off the light. |
| REGISTER EVENT | Categorizes your videos according to events (such as "Travel", "Athletic Event") by registering the file before recording. |
| VIDEO QUALITY | Sets the video quality. |
| ZOOM | Sets the maximum zoom ratio. |
| GAIN UP | Makes the subject appear bright automatically when recording in dark places. |
| TIME-LAPSE RECORDING | Enables the changes of a scene that occur slowly over a long period to be shown within a short time by taking frames of it at a certain interval. |
| AUTO REC | Enables the unit to start or stop recording automatically by sensing the changes in brightness within the red frame displayed on the LCD monitor. |
| SEAMLESS RECORDING | Automatically switches to a different media and continues recording when the remaining space on the current recording media runs out. For example, when the remaining space on the SD card runs out during recording, the recording continues on the built-in memory without stopping. |
| x.v.Color | Records with "x.v.Color". |
| WIND CUT | Reduces the noise caused by wind. |