


## Interior



### 1 Speaker

- Outputs audio sound during video playback.

### 2 (Play) Button

- Switches between the recording and playback modes.

### 3 / (Video/Still Image) Button

- Switches between video and still image.

### 4 UPLOAD/EXPORT\* (Upload/Export to iTunes\*) Button

- Recording: Takes videos in YouTube™ or iTunes\* format.
- Playback: Changes the video to YouTube™ or iTunes\* format.  
(\*GZ-HM350/GZ-HM330 only)

### 5 (Power/Info) Button

- Recording: Displays the remaining time (for video only) and battery power.
- Playback: Displays file information such as recording date.
- Press and hold to turn the power on/off while the LCD monitor is opened.

### 6 AV Terminal

- Connects to a TV.

### 7 COMPONENT Terminal

- Connects to a TV.

### 8 HDMI Terminal

- Connects to an HDMI TV.