## REC MEDIA FOR VIDEO (GZ-HM350/GZ-HM330)

Sets the recording/playback media of videos.

Setting	Details
BUILT-IN MEMORY	Records videos to this unit's built-in memory.
SD CARD	Records videos to the SD card.

## Displaying the Item

1 Touch (em) to display the menu.



2 Select "MEDIA SETTINGS" and touch ®.



3 Select "REC MEDIA FOR VIDEO", and touch ⊚.

