## REC MEDIA FOR IMAGE (GZ-HM350/GZ-HM330)

Sets the recording/playback media of still images.

Setting	Details
BUILT-IN MEMORY	Records still images to this unit's built-in memory.
SD CARD	Records still images to the SD card.

## **Displaying the Item**

1 Touch (a) to display the menu.



2 Select "MEDIA SETTINGS" and touch @.



3 Select "REC MEDIA FOR IMAGE" and touch @s.

