## **VIDEO QUALITY**

Sets the video quality.

Setting	Details
UXP	Enables recording in the best picture quality. Applies to BDs only. To save to DVDs, it is necessary to re-encode the videos to XP mode using the provided software.
XP	Enables recording in high picture quality.
SP	Enables recording in standard quality.
EP	Enables long recordings.

## Memo:-

- Set to UXP or XP mode when recording fast-moving scenes or scenes with extreme change of brightness to avoid noise.
- Use a BD writer to save videos recorded in UXP mode.

## Displaying the Item

1 Select video mode.



 $\boldsymbol{2}$  Touch  $\ensuremath{\textcircled{@}}$  to display the menu.



3 Select "VIDEO QUALITY" and touch @.

