


Setting Shutter Speed (GZ-HM350/GZ-HM330)


You can set the shutter speed to suit the type of subject.

- 1 Touch  to display the menu.



- 2 Select "MANUAL SETTING" and touch .



- 3 Select "SHUTTER SPEED" and touch .



- 4 Select "MANUAL" and touch .



- 5 Select the shutter speed with the slider.



- Shutter speed can be set from 1/2 to 1/4000.
- Slide upward to increase the shutter speed.
- Slide downward to decrease the shutter speed.

- 6 Touch  to confirm.



Memo:

- It is recommended to use a tripod when recording with a slow shutter speed.