Formatting the USB External Hard Disk Drive

1 Select video or still image mode.

2 Select "FORMAT" and touch ⓀK.

3 Select "YES" and touch ⓀK.

● After formatting, touch ⓀK.