


VIDEO SLOT SELECTION (GZ-HM300)

Sets the recording/playback media of videos.

| Setting | Details                                  |
|---------|------------------------------------------|
| SLOT A  | Records videos to the SD card in slot A. |
| SLOT B  | Records videos to the SD card in slot B. |

Displaying the Item

1 Touch  to display the menu.



2 Select “MEDIA SETTINGS” and touch .



3 Select “VIDEO SLOT SELECTION” and touch .

