

Unable to delete folder in USB external hard disk drive.

Delete the folder using a PC.

(When files are added or folders moved/renamed with a PC, they cannot be deleted on this unit.)