

VIDEO QUALITY


Sets the video quality.

Setting	Details
UXP	Enables recording in the best picture quality. • Applies to BDs only. Videos taken in high-definition quality cannot be saved to DVDs.
XP	Enables recording in high picture quality.
SP	Enables recording in standard quality.
EP	Enables long recordings.


- Memo:**—
- Set to UXP or XP mode when recording fast-moving scenes or scenes with extreme change of brightness to avoid noise.
 - Use a BD writer to save videos recorded in UXP mode.
 - You can change the video quality from the remaining recording time display.
Select the video quality with the slider and touch .

Displaying the Item

1 Select video mode.



2 Touch  to display the menu.



3 Select "VIDEO QUALITY" and touch .

