



Editing Playlists

You can change the content of a created playlist.

- 1 Select the playback mode.



- 2 Select video mode.



- 3 Touch to display the menu.



- 4 Select "EDIT PLAYLIST" and touch .



- 5 Select "EDIT" and touch .



- 6 Select the playlist you want to edit and touch .



- 7 Select the file to add to playlist and touch .



- Touch "CHECK" to check the selected video.

- 8 Touch to insert the video onto the right side.



- Repeat steps 7-8 and arrange the videos in the playlist.
- To change the position of a video, select the insertion point with the slider after step 7 and touch .
- To delete a video from the playlist, touch "→" to select the video and touch .

- 9 After arranging, touch .



- 10 Select "SAVE AND THEN QUIT" and touch .

