


Connecting via the Component Connector (GZ-HM30/GZ-HM50)

You can connect this unit to the component connector of a TV to play back videos in analog high-definition quality.


- Refer also to the instruction manual of the TV in use.

Memo :


To select/move cursor towards up/left or down/right, press the button UP/< or DOWN/>.



1 Connect to a TV.



2 Connect the AC adapter to this unit.



- This unit powers on automatically when the AC adapter is connected.

3 Press the external input button on the TV to switch to the input from this unit via the connected connector.



4 Play back a file.



Memo :

- To play back with date/time display, set "DISPLAY ON TV" in the "CONNECTION SETTINGS" menu to "ON".
- When playing back in HD quality, set "COMPONENT OUTPUT" in the "CONNECTION SETTINGS" menu to "1080i/720p".
- The video is output in standard quality if the setting remains at "480i".
- Component and composite (AV) cannot be output at the same time.
- For questions about the TV or method of connection, contact your TV's manufacturer.