


Connecting via the AV Connector

By connecting the supplied AV cable to the AV connector, videos can be played back on a TV.


- Refer also to the instruction manual of the TV in use.

Memo : _____


To select/move cursor towards up/left or down/right, press the button UP/< or DOWN/>.



1 Connect to a TV.



2 Connect the AC adapter to this unit.



- This unit powers on automatically when the AC adapter is connected.

3 Press the external input button on the TV to switch to the input from this unit via the connected connector.



4 Play back a file.



Memo : _____

- To play back with date/time display, set "DISPLAY ON TV" in the "CONNECTION SETTINGS" menu to "ON".
- For questions about the TV or method of connection, contact your TV's manufacturer.