

Unable to turn off the BACK-UP menu.

Turn off the power of this unit or remove the AC adapter.