

Playback Menu (Video)

You can delete or look for specific videos.

Setting	Details
DELETE	Deletes unwanted videos.
PROTECT/CANCEL	Protects files from being deleted accidentally.
SEARCH DATE	Refines the index screen of videos according to recording date.
PLAYBACK OTHER FILE	Plays videos with defective management information.
CLOCK ADJUST	Resets the current time or sets to the local time when using this unit overseas.
ON-SCREEN DISPLAY	Sets whether to show on-screen displays such as icons during playback.