

---

**MAXIMUM QUANTITY RECORDING FOLDERS/FILES HAS BEEN REACHED**

- ① Move the files or folders to a computer or other device. (Back up your files.)
- ② Select “FILE + MANAGEMENT NO” in “FORMAT SD CARD” of the “MEDIA SETTINGS” menu. (All data on the SD card will be deleted.)