


## Protecting Selected Files

Protects or releases protection of the selected files.

### Memo :

To select/move cursor towards up/left or down/right, press the button UP/< or DOWN/>.




- 1 Select the playback mode.




- 2 Press MENU.



- 3 Select "PROTECT/CANCEL" and press OK.



- 4 Select "FILE SELECT" and press OK.




- To exit, press MENU, select "YES" and press OK.

- 5 Select the files to protect or release protection of and press OK.



- A protect mark  appears on the selected file.  
To remove the protect mark , press OK again.
- To move to the next page on the index screen, slide along the  (zoom) lever.
- If the transmission mode of Eye-Fi Helper is set to "Share Selected Files Only" or "Transmit Selected Files Only",  will be displayed.

- 6 After selecting all the files to protect or release protection of, press MENU.



- 7 Select "YES" and press OK.

- To cancel the protection, select "NO" and press OK.