

Recording cannot be performed.

Set to the recording mode with the  (Play/Record) button.