
## **Date Search**

You can search and play videos according to recording dates.

## Memo

To select/move cursor towards up/left or down/right, press the button UP/< or DOWN/>.



1 Select the playback mode.




2 Press MENU.



3 Select "SEARCH DATE" and press OK.



4 Press UP/< or DOWN/> to select a recording date and press OK.



- To cancel and return to the previous screen, press MENU.
- 5 Select the desired video and press OK or ▶/▮▮.



- Only the files recorded on the selected date are displayed.
- To cancel and return to the previous screen, press MENU.
- To move to the next page on the index screen, slide along the (zoom) lever.