


## Capturing Human Subjects Clearly (Face Detection AE/AF)


“FACE PRIORITY AE/AF” automatically adjusts the detected face with appropriate focus and brightness.

### Memo :

To select/move cursor towards up/left or down/right, press the button UP/< or DOWN/>.




1 Press MENU.




2 Select “FACE PRIORITY AE/AF” and press OK.



3 Select “ON” and press OK.




4 Point the camera toward the human subject.



- A frame appears around the face of the subject, and the focus and brightness are automatically adjusted.
- If multiple faces are detected, the face that is closest to the camera will be focused.

5 Start recording.



### Caution :

- When “FACE PRIORITY AE/AF” is set to “ON”, the following settings will change.
  - If “SCENE SELECT” is set to “SPOTLIGHT”, it will be switched to “OFF”.
  - If “FOCUS” is set to “MANUAL”, it will be switched to “AUTO”.
  - If “BACKLIGHT COMP.” is set to “ON”, it will be switched to “OFF”.
- When the following settings are made, “FACE PRIORITY AE/AF” will switch to “OFF”.
  - When “SCENE SELECT” is set to “SPOTLIGHT”
  - When “FOCUS” is set to “MANUAL”
  - When “BACKLIGHT COMP.” is set to “ON”

### Memo :

- The camera is able to detect up to 16 faces.
- Some faces may not be detected depending on the shooting environment.
- If appropriate results cannot be obtained, record with “FACE PRIORITY AE/AF” set to “OFF”.