

CLOCK ADJUST

Resets the current time or sets to the local time when using this unit overseas.

Setting	Details
CLOCK SETTING	Resets the current time or changes the settings.
AREA SETTING	Sets to the local time when using this unit overseas simply by selecting the destination.
DST SETTING	Sets whether daylight saving time is observed at the travel destination.


Memo :

- Daylight saving time is the system of setting the clock 1 hour ahead for a fixed period in summer. It is used mainly in the Western countries.


Displaying the Item

Memo :

To select/move cursor towards up/left or down/right, press the button UP/< or DOWN/>.



- 1 Press MENU.



- 2 Select "CLOCK ADJUST" and press OK.

