

## Media Settings Menu

You can perform various settings for the recording media.

| Setting        | Details                           |
|----------------|-----------------------------------|
| FORMAT SD CARD | Deletes all files on the SD card. |