

شارژ کردن بسته باتری در سایر کشورها

شکل خروجی برق در کشورها و مناطق مختلف فرق می کند.
برای شارژ بسته باتری، به یک مبدل پریز برای تطابق با شکل خروجی نیاز دارید.

A	B	BF	C	O
				

North America		Europe		Oceania		Middle East	
United States	A	Iceland	C	Australia	O	Israel	C
Canada	A	Ireland	C	Guam	A	Iran	C
Mexico	A	United Kingdom	B BF	Tahiti	C	Kuwait	B C
		Italy	C	Tonga	O	Jordan	B BF
Asia		Austria	C	New Zealand	O		
India	B C BF	Netherlands	C	Fiji	O	Africa	
Indonesia	C	Canary Islands	C	Latin		Algeria	A B BF C
Singapore	B BF	Greece	C			Egypt	B BF C
Sri Lanka	B C BF	Switzerland	C	Argentina	O	Guinea	C
Thailand	A BF C	Sweden	C	Colombia	A	Kenya	B C
South Korea	A C	Spain	A C	Jamaica	A	Zambia	B BF
China	A B BF C O	Denmark	C	Chile	B C	Tanzania	B BF
Japan	A	Germany	C	Haiti	A	Republic of South Africa	
Nepal	C	Norway	C	Panama	A		B C BF
Pakistan	B C	Hungary	C	Bahamas	A	Mozambique	C
Bangladesh	C	Finland	C	Puerto Rico	A	Morocco	C
Philippines	A BF O	France	C	Brazil	A C		
Vietnam	A C	Belgium	C	Venezuela	A		
Hong Kong Special		Poland	B C	Peru	A C		
Administrative Region	B BF	Portugal	B C				
Macau Special		Romania	C				
Administrative Region	B C						
Malaysia	B BF C						