
Interior



- 1 Speaker
 - Outputs audio sound during video playback.
- 2 i.AUTO Button
 - Switches between Intelligent Auto and Manual modes.
- 3 USER Button
- 4 ▲ / 🗅 (Video/Still Image) Button
 - Switches between video and still image modes.
- 5 INFO (Information) Button
 - Recording: Displays the remaining time (for video only) and battery power.
 - Playback: Displays file information such as recording date.
- 6 AV Connector
 - Connects to a TV, etc.
- 7 (Dewer) Button
 - Press and hold to turn the power on/off while the LCD monitor is opened.
- 8 HDMI Connector
 - Connects to an HDMI TV.
- 9 USB Connector
 - Connects to computer using a USB cable.