

REC MEDIA FOR IMAGE (GZ-HM650/GZ-HM655)

Sets the recording/playback media of still images.

Setting	Details
BUILT-IN MEMORY	Records still images to this unit's built-in memory.
SD CARD	Records still images to the SD card.

Displaying the Item

1 Tap "MENU".



2 Tap .



3 Tap "REC MEDIA FOR IMAGE".

