


REC VIDEO TO SLOTS (GZ-HM440/GZ-HM445/GZ-HM446)

Sets the recording/playback SD card slot of videos.

Setting	Details
SLOT A	Records videos to the SD card in slot A.
SLOT B	Records videos to the SD card in slot B.

Displaying the Item

1 Tap “MENU”.



2 Tap .



3 Tap “REC VIDEO TO SLOTS”.

