
Images do not appear on the TV properly.

Disconnect the cable and connect again.
Turn off and on this unit again.