## LIGHT (GZ-HM445/GZ-HM446/GZ-HM650/GZ-HM655)

Turns on/off the light.

Setting	Details
OFF	Does not light up.
AUTO	Lights up automatically when the surrounding is dark.
ON	Lights up at all times.

## Displaying the Item


1 Select still image mode.



2 Tap • to select the recording mode.



- The mode changes between recording and playback with every tap.
- 3 Tap "MENU".



4 Tap "LIGHT".

