


Connecting via the Component Connector

You can connect this unit to the component connector of a TV to play back videos in analog high-definition quality.


- Refer also to the instruction manual of the TV in use.

1 Connect to a TV.



- Turn off the camcorder by pressing the  button for about 2 seconds.

2 Connect the AC adapter to this unit.



AC Adapter
To AC Outlet
(110 V to 240 V)

* The AC adapter shown in the illustration is AC-V10M.

3 Press the external input button on the TV to switch to the input from this unit via the connected connector.



4 Play back a file.



Memo :

- When playing back in HD quality, set "COMPONENT OUTPUT" in the common menu to "1080i".
- The video is output in standard quality if the setting remains at "480i".
- For questions about the TV or method of connection, contact your TV's manufacturer.