
Recording Videos to Discs

Copy the files that are arranged using the user list to DVDs.

- 1 Insert a new disc into the PC's recordable DVD or Blu-ray drive.
- 2 Select the desired user list.



3 Select the files to copy to disc in order.



- Click "Settings" to select the disc type.

 Image quality is set to standard when DVD-Video is selected.
- Click "Select all" to select all the displayed files.
- After selecting, click "Next".
- 4 Set the title of the top menu of the disc.



- Click "Settings" to select the menu background.
- After setting, click "Start".
- 5 After copying is complete, click "OK".

Memo:

- The following types of discs can be used on the provided software Everio MediaBrowser 3 BE.
 - -DVD-R
 - -DVD-R DL
 - -DVD-RW
 - -DVD+R
 - -DVD+R DL
 - -DVD+RW
 - -BD-R
 - -BD-R DL
 - -BD-RE
 - -BD-RE DL
- The following formats are supported by the provided software Everio MediaBrowser 3 BE.
 - -Blu-ray
 - -DVD-Video
 - -AVCHD
- Use Everio MediaBrowser 3 BE Player to play back a Blu-ray or AVCHD disc. Refer to the help file of the provided Everio MediaBrowser 3 BE software to operate.
- To view the help file of Everio MediaBrowser 3 BE, select "Help" from the Everio MediaBrowser 3 BE's menu bar or press F1 on the keyboard.
- If you encounter any problems with the provided software Everio MediaBrowser 3 BE, please consult the "Pixela User Support Center".

Telephone	USA and Canada (English): +1-800-458-4029 (toll-free) Europe (UK, Germany, France, and Spain) (English/German/French/Spanish): +800-1532-4865 (toll-free) Other Countries in Europe (English/German/French/Spanish): +44-1489-564-764 Asia (Philippines) (English): +63-2-438-0090 China (Chinese): 10800-163-0014 (toll-free)
Homepage	http://www.pixela.co.jp/oem/jvc/mediabrowser/e/