



## Finalizing Discs After Copying

Finalize the disc after copying is finished. This enables the disc to be played back using this unit, PC, DVD writer, DVD player, or external Blu-ray drive that supports the BD-MV and AVCHD formats.


- 1 Select video or still image mode.



- 2 Tap "FINALIZE".



- 3 Tap "YES".



- After finalizing, tap "OK".