

GAIN


Enables selection of the ISO level.

Setting	Details
AUTO	Adjusts the ISO level automatically according to the brightness of the subject.
ISO100 / ISO200 / ISO400 / ISO800 / ISO1600 / ISO3200 / ISO6400	Records with a fixed ISO level.

- Memo :**
- The flash cannot be used when “ISO6400” is set.
 - The higher the ISO level, the grainier the image becomes due to noise.

Displaying the Item

1 Select still image mode.



2 Tap “MENU”.



3 Tap “GAIN”.

