

VIDEO QUALITY


Sets the video quality.

Setting	Details
UXP	Enables recording in the best picture quality. ● Applies to Blu-ray discs only. Videos taken in high-definition quality cannot be saved to DVDs.
XP	Enables recording in high picture quality.
SP	Enables recording in standard quality.
EP	Enables long recordings.


- Memo :**
- Set to “UXP” or “XP” mode when recording fast-moving scenes or scenes with extreme changes of brightness to avoid noise.
 - Use an external Blu-ray drive to save videos recorded in “UXP” mode.
 - You can change to the desired “VIDEO QUALITY” by tapping on it from the remaining recording time display.

Displaying the Item

1 Select video mode.



2 Tap “MENU”.



3 Tap “VIDEO QUALITY”.

