

Still Image Playback



- 1 Still Image Mode
- 2 Folder Number
- 3 File Number
- 4 Date/Time
- 5 Media
- 6 Battery Indicator
- 7 External Storage Playback
- 8 1080p Output
- 9 Radio Reception Status (for GZ-HM970/GZ-HM870/GZ-HM860)