


## Using the Remote Control

You can operate this unit from a distance away using the supplied remote control.




### Memo :

- Point the remote control toward the sensor directly and use it within 5 m from this unit.
- The transmitted beam may not be effective or may cause incorrect operation when the sensor is directly exposed to sunlight or powerful lighting.

## Preparing the Remote Control




## Using the Remote Control for the First Time




- A button battery (CR2025) is included inside the remote control at the time of purchase.  
Remove the insulation sheet before use.

## Reinserting the Battery



- Pull out the battery holder by pressing the lock tab.
- Insert the button battery with the + side facing upward.

## Operation Buttons on Remote Control Unit



- 1 Recording Start/Stop Button**
  - Starts/stops video recording.
- 2 Still Image Button**
  - Takes a still image.
- 3 Zoom Button**
  - T: Zooms in
  - W: Zooms out
- 4 Basic Playback Operations**

| Operation Button             | Description                                                                                                                            |
|------------------------------|----------------------------------------------------------------------------------------------------------------------------------------|
| Playback/Pause Button<br>▶ / | <ul style="list-style-type: none"> <li>• Starts/pauses playback of videos or slideshows.</li> </ul>                                    |
| Left Button ◀◀               | <ul style="list-style-type: none"> <li>• Moves the cursor to the left.</li> <li>• Performs reverse search during playback.</li> </ul>  |
| Right Button ▶▶              | <ul style="list-style-type: none"> <li>• Moves the cursor to the right.</li> <li>• Performs forward search during playback.</li> </ul> |
| T Button T                   | <ul style="list-style-type: none"> <li>• Turns up (+) the volume during video playback.</li> </ul>                                     |
| W Button W                   | <ul style="list-style-type: none"> <li>• Turns down (-) the volume during video playback.</li> </ul>                                   |

- 5 Index Button**
  - Stops playback and returns to index screen.
- 6 Info Button**
  - Recording: Displays the remaining time (for video only) and battery power.
  - Playback: Displays file information such as recording date.