


ZOOM MIC

Sets the zoom microphone.

| Setting | Details                                                           |
|---------|-------------------------------------------------------------------|
| OFF     | Deactivates the zoom microphone.                                  |
| ON      | Records audio sounds in the same direction as the zoom operation. |

Displaying the Item

1 Select video mode.



2 Tap “MENU”.



3 Tap “ZOOM MIC”.

