



Protecting Selected Files

Protects or releases protection of the selected files.

- 1 Select the playback mode.



- 2 Select video or still image mode.



- 3 Touch to display the menu.




- 4 Select "EDIT" and touch .



- 5 Select "PROTECT/CANCEL" and touch .



- 6 Select "FILE SELECT" and touch .



- 7 Select the desired file and touch .



- A mark appears on the selected file.

To remove the mark, touch again.

- Touch "CHECK" to check the selected file.

- 8 After selecting all the files to protect or release protection of, touch .



- 9 Select "YES" and touch .

