## **IMAGE QUALITY**

Sets the image quality.

Setting	Details
FINE	Enables recording in high picture quality, but number of recordable images becomes lesser.
STANDARD	Enables recording in standard quality.

## Displaying the Item

1 Select still image mode.



2 Touch em to display the menu.



3 Select "IMAGE QUALITY" and touch <sup>™</sup>.

