## LANGUAGE

The language on the display can be changed.

1 Touch ⓜ to display the menu.

2 Select "DISPLAY SETTINGS" and touch ⓞⓚ.

3 Select "LANGUAGE" and touch ⓞⓚ.

4 Select the desired language and touch ⓞⓚ.