


Clock Setting

The "SET DATE/TIME!" screen appears when you turn on this unit for the first time after purchase, when it has not been used for a long time, or when the clock is not set yet.

Set the clock before recording.

- 1 Open the LCD monitor.





- This unit turns on.
- When the LCD monitor is closed, this unit turns off.

- 2 Select "YES" and touch .




- 3 Set the date and time.



- Use the slider to adjust the year, month, day, hour, and minute in order.
- Touch the operation buttons "←" / "→" to move the cursor.
- After setting the date and time, touch .

- 4 Select the region where you live and touch .



- The city name and time difference are displayed.
- Touch  after the color of the selected region changes.

Memo :

- The clock can be reset again later.
- When using this unit overseas, you can set it to the local time for recording.
- You can turn on or off the clock display during playback mode.
- The clock set style of this unit varies with the models.
- Touch the slider and buttons around the screen with your fingers.
- The slider and buttons do not function if you touch them with your fingernails or with gloves on.
- The displays on the screen do not work even if you touch them.