DROP DETECTION

Prevents damage to the HDD when this unit is dropped.

Setting	Details
OFF	Deactivates the function.
ON	Turns off the power of this unit automatically when a drop is detected.

Caution:-

• This function does not guarantee total protection to the HDD.

Displaying the Item

1 Touch (10) to display the menu.



2 Select "BASIC SETTINGS" and touch ⊚.



3 Select "DROP DETECTION" and touch ⊚.

