


ON-SCREEN DISPLAY

Sets whether to show on-screen displays such as icons during playback.


| Setting           | Details                 |
|-------------------|-------------------------|
| OFF               | No display at all.      |
| DISPLAY ALL       | Displays everything.    |
| DISPLAY DATE ONLY | Displays the date only. |

Displaying the Item


- 1 Select the playback mode.



- 2 Select video mode.



- 3 Touch  to display the menu.



- 4 Select "ON-SCREEN DISPLAY" and touch .

