


ON-SCREEN DISPLAY

Sets whether to show on-screen displays such as icons during playback.


Setting	Details
OFF	No display at all.
DISPLAY ALL	Displays everything.
DISPLAY DATE ONLY	Displays the date only.


Displaying the Item


- 1 Select the playback mode.



- 2 Select still image mode.



- 3 Touch  to display the menu.



- 4 Select "ON-SCREEN DISPLAY" and touch .

