


## DEMO MODE

Starts playback of the demo mode which introduces the features of this unit.

Setting	Details
OFF	Deactivates the function.
ON	Plays a demonstration of the special features of this unit.


## Displaying Demo Mode


- 1 Remove the battery pack and SD card.
  - 2 Connect the AC adapter.
  - 3 Open the LCD monitor and turn on the power.
- Demonstration starts playing after 3 minutes.
  - To stop playback, touch .

### Memo :

- This mode is not available in the playback mode.

## Displaying the Item

- 1 Touch  to display the menu.



- 2 Select "BASIC SETTINGS" and touch .



- 3 Select "DEMO MODE" and touch .

