


## REC MEDIA FOR IMAGE

Sets the recording/playback media of still images.

| Setting | Details                                   |
|---------|-------------------------------------------|
| HDD     | Records still images to this unit's HDD.  |
| SD      | Records still images to the microSD card. |

## Displaying the Item

- 1 Touch  to display the menu.



- 2 Select "MEDIA SETTINGS" and touch .



- 3 Select "REC MEDIA FOR IMAGE" and touch .

