COMPONENT OUTPUT

Sets the definition of the video output from the COMPONENT connector.

Setting	Details
576i	Outputs at 576i.
1080i	Outputs at 1080i.

Displaying the Item

1 Touch ⊛ to display the menu.

2 Select "CONNECTION SETTINGS" and touch ⊛.

3 Select "COMPONENT OUTPUT" and touch ⊛.