## Charger la batterie à l'étranger

La forme de la prise de courant varie en fonction des pays et des régions. Pour charger la batterie, vous avez besoin d'une prise convertisseur adaptée à la forme de la prise.




| North America | |
|---|---|
| United States | A |
| Canada | A |
| Mexico | A |

| Asia | |
|---|---|
| India | B,C,BF |
| Indonesia | C |
| Singapore | B,BF |
| Sri Lanka | B,C,BF |
| Thailand | A,BF,C |
| South Korea | A,C |
| China | A,B,BF,C,O |
| Nepal | C |
| Pakistan | B,C |
| Bangladesh | C |
| Philippines | A,BF,O |
| Vietnam | A,C |
| Hong Kong Special Administrative Region | B,BF |
| Macau Special Administrative Region | B,C |
| Malaysia | B,BF,C |

| Europe | |
|---|---|
| Iceland | C |
| Ireland | C |
| United Kingdom | B,BF |
| Italy | C |
| Austria | C |
| Netherlands | C |
| Canary Islands | C |
| Greece | C |
| Switzerland | C |
| Sweden | C |
| Spain | A,C |
| Denmark | C |
| Germany | C |
| Norway | C |
| Hungary | C |
| Finland | C |
| France | C |
| Belgium | C |
| Poland | B,C |
| Portugal | B,C |
| Romania | C |

| Oceania | |
|---|---|
| Australia | O |
| Guam | A |
| Tahiti | C |
| Tonga | O |
| New Zealand | O |
| Fiji | O |

| Latin | |
|---|---|
| Argentina | BF,C,O |
| Colombia | A |
| Jamaica | A |
| Chile | B,C |
| Haiti | A |
| Panama | A |
| Bahamas | A |
| Puerto Rico | A |
| Brazil | A,C |
| Venezuela | A |
| Peru | A,C |

| Tyuukintou | |
|---|---|
| Israel | C |
| Iran | C |
| Kuwait | B,C |
| Jordan | B,BF |

| Africa | |
|---|---|
| Algeria | A,B,BF,C |
| Egypt | B,BF,C |
| Guinea | C |
| Kenya | B,C |
| Zambia | B,BF |
| Tanzania | B,BF |
| Republic of South Africa | B,C,BF |
| Mozambique | C |
| Morocco | C |