


Recording at Intervals (TIME-LAPSE RECORDING)


This function enables the changes of a scene that occur slowly over a long period to be shown within a short time by taking frames of it at a certain interval.

This is useful for making observations such as the opening of a flower bud.

1 Select video mode.



2 Touch **MENU** to display the menu.



3 Select "TIME-LAPSE RECORDING" and touch **OK**.




4 Select a recording interval (1 to 80 seconds) and touch **OK**.




- The greater the number of seconds, the longer the recording interval.

5 Start recording.



- A frame is taken at intervals of the selected period.
- When the recording interval is set to "20SEC INTERVAL" or higher, this unit switches to the power-saving mode between recordings. At the next point to record, the power-saving mode will be turned off and recording will start automatically.
- Press the START/STOP button again to stop recording.



| Display | Description |
|---------------------------------|---|
| Speed Indicator | Displays the recording interval that is set. |
| Video Quality | Displays the icon of the video quality that is set. |
| Remaining Recording Time | Remaining time left to record with the currently selected video quality. |
| Recording in Progress | Appears when video recording is in progress. When in the power-saving mode, it blinks. |
| Record-Standby | Appears when video recording is paused. |
| Actual Elapsed Time | Displays the actual elapsed time after recording starts. |
| Recorded Time | Displays the actual recorded time of the video. Recorded time increases in units of frames. |

Indications During Time-Lapse Recording

Time-Lapse Setting

The greater the number of seconds, the longer the recording interval.

| Setting | Details |
|-----------------------|--|
| OFF | Deactivates the function. |
| 1SEC INTERVAL | Takes a frame at 1-second intervals. Recorded videos will be played back at 30 times speed. |
| 2SEC INTERVAL | Takes a frame at 2-second intervals. Recorded videos will be played back at 60 times speed. |
| 5SEC INTERVAL | Takes a frame at 5-second intervals. Recorded videos will be played back at 150 times speed. |
| 10SEC INTERVAL | Takes a frame at 10-second intervals. Recorded videos will be played back at 300 times speed. |
| 20SEC INTERVAL | Takes a frame at 20-second intervals. Recorded videos will be played back at 600 times speed. |
| 40SEC INTERVAL | Takes a frame at 40-second intervals. Recorded videos will be played back at 1 200 times speed. |
| 80SEC INTERVAL | Takes a frame at 80-second intervals. Recorded videos will be played back at 2 400 times speed. |

Caution :

- Audio cannot be recorded during time-lapse recording.
- Zooming, simultaneous still image recording, and image stabilizer are not available in time-lapse recording.
- When recording is stopped with the recorded time less than "0:00:00:17", the video will not be saved.
- Automatic switching of recording media is disabled in time-lapse recording.
- Image quality cannot be changed after time-lapse shooting is selected. Set it before selecting time-lapse shooting.

Memo :

- Settings of time-lapse recording are saved even when the power is turned off.
When the power is turned on, "TIME LAPSE" appears on the screen.
- Recording stops automatically 99 hours after it is started.
- Make use of a tripod and AC adapter for time-lapse recordings with long intervals.
It is also recommended to fix the focus and white balance manually.